YAMAHA

PARTS CATALOGUE

CZD300-AK (B74C) AUSTRALIA,NEW ZEALAND

YAMAHA GENUINE Parts & Accessories

1UB74-700E1

( )

CZD300-AK
PARTS CATALOGUE
©2018 by Yamaha Motor Co., Ltd.
1st edition, October 2018
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.
   "UR" Use specified parts number.
   "UN" Use as many as needed.
   "AP" Alternate Parts
   "LM" Locally Made (Parts need to be ordered locally)
   "F#" Frame No. (Applicable machine No.)
   "O/S" Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



Frame Serial No.




8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
MBL2(*)	MAT BLACK 2	0582
MS1(*)	MAT SILVER 1	1160
SMX	BLACK METALLIC X	0903
YB	YAMAHA BLACK	0033


MODEL LABEL

(1) A label called “Model Label” is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross–reference the “model code – production code No.” in the catalogue with the “model code – production code No.” indicated on the Model Label affixed onto the product concerned.


(2) “Model Label” Indication



a: Model Type Code
b: Production Code No.
c: Colouring Type



(3) Model Label Affixing Location



(4) Colouring Information

Model Code	Colouring Type Code	Colour Code	Colour Name	Abbrevia-tion
B74C	A	0582	MAT BLACK 2	MBL2
	B	1160	MAT SILVER 1	MS1

(5) Model Code – Production Code Number of Model Listed in This Parts Catalogue

Model Code	Production Code No.	Country (destination)
B74C	010	AUSTRALIA
		NEW ZEALAND
		SOUTH KOREA

Model Code	Production Code No.	Country (destination)

CONTENTS

ENGINE

CYLINDER....1
CRANKSHAFT & PISTON....2
VALVE....4
CAMSHAFT & CHAIN....6
WATER PUMP....7
RADIATOR & HOSE....8
OIL PUMP....10
INTAKE....11
EXHAUST....13
CRANKCASE....14
CRANKCASE COVER 1....16
STARTER....17
CLUTCH....18
TRANSMISSION....20


CHASSIS

FRAME....21
FENDER....22
SIDE COVER....24
REAR ARM & SUSPENSION....26
STEERING....27
FRONT FORK....28
FUEL TANK....30
SEAT....32
FRONT WHEEL....34
FRONT BRAKE CALIPER....35
REAR WHEEL....36
REAR BRAKE CALIPER....37
STEERING HANDLE & CABLE....38
FRONT MASTER CYLINDER....39
STAND & FOOTREST....41
STAND & FOOTREST 2....43
LEG SHIELD....45
WINDSHIELD....48
GENERATOR....51
STARTING MOTOR....52
FLASHER LIGHT....53
METER....54
HEADLIGHT....55
TAILLIGHT....56
HANDLE SWITCH & LEVER....57
ELECTRICAL 1....58
ELECTRICAL 2....60
ELECTRICAL 3....61


INDEX

NUMERICAL INDEX....62

FIG. 1 CYLINDER




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E1102–00	CYLINDER HEAD ASSY	1					
2	B74–E1133–10	.GUIDE, VALVE 1	4					
3	90340–18002	.PLUG, STRAIGHT SCREW	1					
4	95022–06012	BOLT, FLANGE	1					
5	90430–06014	GASKET	1					
6	95612–08620	BOLT, STUD	2					
7	B74–E1998–00	BRACKET 1	1					
8	95022–06012	BOLT, FLANGE	1					
9	B74–E1191–00	COVER, CYLINDER HEAD 1	1					
10	B74–E1185–00	COVER, CYLINDER HEAD SIDE 3	1					
11	B74–E1169–00	GASKET, BREATHER COVER	1					
12	95022–06016	BOLT, FLANGE	3					
13	B74–E1193–00	GASKET, HEAD COVER 1	1					
14	B74–E1999–00	BRACKET 2	1					
15	95022–06025	BOLT, FLANGE	6					
16	90179–10818	NUT	4					
17	90201–10849	WASHER, PLATE	4					
18	B74–11391–00	BOLT, STUD 1	4					
19	94700–00436	PLUG, SPARK (NGK LMAR8A-9)	1					
20	B74–E1181–00	GASKET, CYLINDER HEAD 1	1					
21	99530–14016	PIN, DOWEL	2					
22	99530–14016	PIN, DOWEL	2					
23	90110–06868	BOLT, HEXAGON SOCKET HEAD	2					
24	B74–E1311–00	CYLINDER 1	1					
25	B74–E1351–00	GASKET, CYLINDER	1					



B741303-8020

FIG. 2 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E1400–00	CRANKSHAFT ASSY	1					
2	B74–11650–00	CONNECTING ROD ASSY	1					
3	2C0–11654–00	.BOLT, CONNECTING ROD	2					
4	90179–07001	.NUT	2					
5	B74–11656–00	PLANE BEARING, CONNECTING ROD	2					UR BLUE
	B74–11656–10	PLANE BEARING, CONNECTING ROD	2					UR BLACK
	B74–11656–20	PLANE BEARING, CONNECTING ROD	2					UR BROWN
	B74–11656–30	PLANE BEARING, CONNECTING ROD	2					UR GREEN
6	90105–10883	BOLT, FLANGE	1					
7	90201–10848	WASHER, PLATE	1					
8	90280–05013	KEY, WOODRUFF	1					
9	B74–11416–A0	PLANE BEARING, CRANKSHAFT 1	2					UR WHITE
	B74–11416–00	PLANE BEARING, CRANKSHAFT 1	2					UR BLUE
	B74–11416–10	PLANE BEARING, CRANKSHAFT 1	2					UR BLACK
	B74–11416–20	PLANE BEARING, CRANKSHAFT 1	2					UR BROWN
	B74–11416–30	PLANE BEARING, CRANKSHAFT 1	2					UR GREEN
	B74–11416–40	PLANE BEARING, CRANKSHAFT 1	2					UR YELLOW
	B74–11416–50	PLANE BEARING, CRANKSHAFT 1	2					UR PINK
10	B74–11417–A0	PLANE BEARING, CRANKSHAFT 2	2					UR WHITE
	B74–11417–00	PLANE BEARING, CRANKSHAFT 2	2					UR BLUE
	B74–11417–10	PLANE BEARING, CRANKSHAFT 2	2					UR BLACK
	B74–11417–20	PLANE BEARING, CRANKSHAFT 2	2					UR BROWN
	B74–11417–30	PLANE BEARING, CRANKSHAFT 2	2					UR GREEN
	B74–11417–40	PLANE BEARING, CRANKSHAFT 2	2					UR YELLOW
	B74–11417–50	PLANE BEARING, CRANKSHAFT 2	2					UR PINK
11	B74–E1500–00	BALANCER ASSY	1					
12	93306–303YT	BEARING	1					




B741303-3020

FIG. 2 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
13	93306–204XV	BEARING	1					
14	B74–E1631–01	PISTON (STD)	1					
15	B74–E1603–00	PISTON RING SET (STD)	1					
16	B74–E1633–00	PIN, PISTON	1					
17	93450–17129	CIRCLIP	2					

FIG. 3 VALVE



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E2111–00	VALVE, INTAKE	2					
2	B74–E2121–00	VALVE, EXHAUST	2					
3	54P–E2119–00	SEAL, VALVE STEM	4					
4	B74–E2113–00	SPRING, VALVE INNER	4					
5	5TL–E2118–00	LOCK, VALVE SPRING RETAINER	8					
6	B74–E2117–00	RETAINER, VALVE SPRING	4					
7	2PH–E2126–00	SEAT, VALVE SPRING 2	4					
8	B74–E2151–00	ARM, VALVE ROCKER	1					
9	B74–E2161–00	ARM, VALVE ROCKER 2	1					
10	B74–E2146–00	SHAFT, ROCKER	2					
11	B74–E2662–00	COLLAR 1	2					
12	91312–05014	BOLT, HEXAGON SOCKET HEAD	2					
13	B74–12168–00	PAD, ADJUSTING (1.50)	4					UR
	B74–12168–20	PAD, ADJUSTING (1.55)	4					UR
	B74–12168–40	PAD, ADJUSTING (1.60)	4					UR
	B74–12168–60	PAD, ADJUSTING (1.65)	4					UR
	B74–12168–80	PAD, ADJUSTING (1.70)	4					UR
	B74–12168–A0	PAD, ADJUSTING (1.75)	4					UR
	B74–12168–F0	PAD, ADJUSTING (1.80)	4					UR
	B74–12168–H0	PAD, ADJUSTING (1.85)	4					UR
	B74–12168–K0	PAD, ADJUSTING (1.90)	4					UR
	B74–12168–M0	PAD, ADJUSTING (1.95)	4					UR
	B74–12168–R0	PAD, ADJUSTING (2.00)	4					UR
	B74–12168–U0	PAD, ADJUSTING (2.05)	4					UR
	B74–12168–W0	PAD, ADJUSTING (2.10)	4					UR
	B74–12168–Y0	PAD, ADJUSTING (2.15)	4					UR
	B74–12169–10	PAD, ADJUSTING (2.20)	4					UR





FIG. 3 VALVE


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
13	B74–12169–30	PAD, ADJUSTING (2.25)	4					UR
	B74–12169–50	PAD, ADJUSTING (2.30)	4					UR
	B74–12169–70	PAD, ADJUSTING (2.35)	4					UR
	B74–12169–90	PAD, ADJUSTING (2.40)	4					UR
	B74–12169–E0	PAD, ADJUSTING (2.45)	4					UR
	B74–12169–G0	PAD, ADJUSTING (2.50)	4					UR
	B74–12169–J0	PAD, ADJUSTING (2.55)	4					UR
	B74–12169–L0	PAD, ADJUSTING (2.60)	4					UR
	B74–12169–N0	PAD, ADJUSTING (2.65)	4					UR
	B74–12169–T0	PAD, ADJUSTING (2.70)	4					UR
	B74–12169–V0	PAD, ADJUSTING (2.75)	4					UR
	B74–12169–X0	PAD, ADJUSTING (2.80)	4					UR
	B74–1216A–00	PAD, ADJUSTING (2.85)	4					UR
	B74–1216A–20	PAD, ADJUSTING (2.90)	4					UR
	B74–1216A–40	PAD, ADJUSTING (2.95)	4					UR
	B74–1216A–60	PAD, ADJUSTING (3.00)	4					UR
	B74–1216A–80	PAD, ADJUSTING (3.05)	4					UR
	B74–1216A–A0	PAD, ADJUSTING (3.10)	4					UR
	B74–1216A–F0	PAD, ADJUSTING (3.15)	4					UR
	B74–1216A–H0	PAD, ADJUSTING (3.20)	4					UR
	B74–1216A–K0	PAD, ADJUSTING (3.25)	4					UR
	B74–1216A–M0	PAD, ADJUSTING (3.30)	4					UR
	B74–1216A–R0	PAD, ADJUSTING (3.35)	4					UR
	B74–1216A–U0	PAD, ADJUSTING (3.40)	4					UR
	B74–1216A–W0	PAD, ADJUSTING (3.45)	4					UR
	B74–1216A–Y0	PAD, ADJUSTING (3.50)	4					UR

FIG. 4 CAMSHAFT & CHAIN




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E2170–00	CAMSHAFT ASSY 1	1					
2	93210–12801	.O-RING	1					
3	93306–002XH	BEARING	1					
4	B74–E2176–00	SPROCKET, CAM CHAIN	1					
5	90110–06405	BOLT, HEXAGON SOCKET HEAD	2					
6	B74–E112F–00	PLATE 2	1					
7	90110–06187	BOLT, HEXAGON SOCKET HEAD	1					
8	B74–E111F–00	PLATE	1					
9	95022–06012	BOLT, FLANGE	4					
10	94568–H8110	CHAIN	1					
11	B74–E2231–00	GUIDE, STOPPER 1	1					
12	B74–E2233–00	PLATE, GUIDE STOPPER 1	1					
13	90110–06182	BOLT, HEXAGON SOCKET HEAD	1					
14	B74–E2241–00	GUIDE, STOPPER 2	1					
15	1DB–E2228–00	BOLT	1					
16	31G–12210–01	TENSIONER ASSY, CAM CHAIN	1					
17	31G–12222–00	.PLUG	1					
18	31G–12214–00	.GASKET	1					
19	B74–E2213–00	GASKET, TENSIONER CASE	1					
20	91312–06025	BOLT, HEXAGON SOCKET HEAD	2					

FIG. 5 WATER PUMP




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E2422–00	COVER, HOUSING	1					
2	B74–E2439–00	.O-RING	1					
3	B74–E5417–00	COVER, CAP	1					
4	B74–E2157–00	BOLT	1					
5	90430–10148	GASKET	1					
6	5BP–E5363–10	PLUG, OIL	1					
7	93210–198J0	O-RING	1					
8	95027–06020	BOLT, FLANGE	3					
9	90430–06014	GASKET	1					
10	90340–32805	PLUG, STRAIGHT SCREW	1					
11	93210–32816	O-RING	1					
12	B74–E2450–00	IMPELLER SHAFT ASSY	1					
13	93306–000Y3	BEARING	1					
14	93103–10801	OIL SEAL	1					
15	99009–10400	CIRCLIP	1					
16	5PW–15361–00	GAUGE, LEVEL	1					

FIG. 6 RADIATOR & HOSE




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–12410–00	THERMOSTAT ASSY	1					
2	52S–12439–00	.O-RING	1					
3	95022–06020	BOLT, FLANGE	2					
4	B74–E2576–00	HOSE 1	1					
5	90467–10038	CLIP	2					
6	90464–10802	CLAMP	1					
7	B74–E240A–00	RADIATOR ASSY	1					
8	5ST–E2615–00	.COCK, DRAIN	1					
9	5ST–E2843–00	.O-RING	1					
10	B74–E2405–00	.BLOWER ASSY	1					
11	1WD–E2671–00	.NUT 1	3					
12	5GJ–12675–00	.BOLT, BLOWER HOLDING	3					
13	B74–E2461–00	.RADIATOR COMP	1					
14	90480–15483	GROMMET	1					
15	90387–064W3	COLLAR	1					
16	90201–06033	WASHER, PLATE	1					
17	95827–06025	BOLT, FLANGE	1					
18	90480–14818	GROMMET	2					
19	90467–22002	CLIP	1					
20	90467–24800	CLIP	1					
21	B74–E2481–00	PIPE 1	1					
22	B74–F1823–00	CLAMP, HOSE	1					
23	95022–06012	BOLT, FLANGE	1					
24	B74–F2591–00	CLAMP, HOSE	1					
25	95022–06012	BOLT, FLANGE	1					
26	B74–E2482–00	PIPE 2	1					
27	B74–E2483–00	PIPE 3	1					

FIG. 6 RADIATOR & HOSE




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	90467–20805	CLIP	2					
29	90467–21801	CLIP	2					
30	B74–E2591–00	SUPT, FILLER NECK	1					
31	90269–07007	RIVET	1					
32	B65–E2462–00	CAP, RADIATOR	1					
33	B74–E2484–00	PIPE 4	1					
34	90467–250A1	CLIP	1					
35	90467–26131	CLIP	1					
36	B74–E2467–00	COVER, RADIATOR	1					
37	90109–06887	BOLT	2					
38	90269–06816	RIVET	1					
39	B74–E2446–00	JOINT	1					
40	93210–22800	O-RING	2					
41	95827–06020	BOLT, FLANGE	2					

FIG. 7 OIL PUMP




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E3300–00	OIL PUMP ASSY	1					
2	95022–06060	BOLT, FLANGE	2					
3	94568–F9058	CHAIN	1					
4	4ST–E3411–00	STRAINER, OIL	2					
5	5RU–13490–00	RELIEF VALVE ASSY	1					
6	93210–10096	O-RING	1					
7	1S7–E3440–00	ELEMENT ASSY, OIL CLEANER	1					
8	B74–E3447–00	COVER, OIL ELEMENT	1					
9	95022–06020	BOLT, FLANGE	3					
10	93210–48530	O-RING	1					

FIG. 8 INTAKE




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E3585–00	MANIFOLD	1					
2	B74–E3595–00	JOINT	1					
3	93210–40659	O-RING	2					
4	90110–06172	BOLT, HEXAGON SOCKET HEAD	2					
5	B74–E3770–00	INJECTOR ASSY	1					
6	B74–E3761–00	.INJECTOR	1					
7	54P–E4147–00	..O-RING	1					
8	5CA–E4147–00	..O-RING	1					
9	52S–13938–00	.PIPE	1					
10	54P–E4137–00	.CLIP	1					
11	95812–06025	BOLT, FLANGE	1					
12	90450–56009	HOSE CLAMP ASSY	1					
13	B74–E3750–01	THROTTLE BODY ASSY	1					
14	98502–06012	.SCREW, PAN HEAD	1					
15	54P–E4243–00	.PLATE	1					
16	B74–H5801–00	.STEPPING MOTOR	1					
17	54P–E416A–00	..O-RING	1					
18	B74–E4335–00	.SPRING, PLUNGER	1					
19	B74–E4411–00	CASE, AIR CLEANER 1	1					
20	B74–E4412–00	CAP, CLEANER CASE 1	1					
21	B74–E4469–00	FUNNEL, AIR	1					
22	B74–E4437–00	DUCT	1					
23	B74–WE445–00	AIR CLEANER ELEMENT ASSY	1					
24	B74–E4452–00	SEAL	2					
25	97707–50025	SCREW, TAPPING	8					
26	97707–50035	SCREW, TAPPING	1					
27	52B–E443E–00	PIPE, DRAIN	1					

FIG. 8 INTAKE



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	90467–12809	CLIP	1					
29	B74–E4449–00	COLLAR	2					
30	B74–E4435–00	GROMMET	2					
31	5TP–E443G–10	PIPE, DRAIN 2	1					
32	90467–12809	CLIP	1					
33	B74–E4417–00	COVER 1	1					
34	B74–E4462–00	SEAL	1					
35	97702–50020	SCREW, TAPPING	5					
36	90338–14802	PLUG	3					
37	95812–06030	BOLT, FLANGE	2					
38	90450–52008	HOSE CLAMP ASSY	1					
39	B74–E1166–00	PIPE, BREATHER 1	1					
40	90467–13808	CLIP	1					
41	90467–14807	CLIP	1					
42	90520–10836	DAMPER, PLATE	1					
43	B74–E447F–00	ELEMENT 3	1					

FIG. 9 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E4611–00	PIPE, EXHAUST 1	1					
2	B74–E4711–00	MUFFLER 1	1					
3	54D–E4714–00	GASKET, MUFFLER	1					
4	1WD–E4715–00	BAND, MUFFLER	1					
5	95027–08035	BOLT, FLANGE	1					
6	B74–E4718–00	PROTECTOR, MUFFLER 1	1					
7	90111–06807	BOLT,HEX. SOCKET BUTTON	3					
8	90480–10332	GROMMET	2					
9	B74–E4799–00	CAP	1					
10	B74–E475P–00	SEAT	1					
11	B74–E476P–00	SEAT	1					
12	B74–E477P–00	SEAT	1					
13	1WD–E4613–00	GASKET, EXHAUST PIPE	1					
14	95702–08500	NUT, FLANGE	2					
15	95817–10045	BOLT, FLANGE	3					




FIG. 10 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E5150–00	CRANKCASE ASSY	1					
2	5D9–E5155–00	NOZZLE 3	1					
3	B74–E5372–00	COLLAR, UNION	2					
4	B74–E5378–00	HOLDER	2					
5	90201–18262	WASHER, PLATE	2					
6	99009–18400	CIRCLIP	2					
7	93210–18397	O-RING	4					
8	5MX–F2216–00	BUSH, REAR SHOCK ABSORBER	1					
9	40D–E1126–00	PIPE, BREATHER 3	1					
10	B74–E5373–00	PIPE, BREATHER	1					
11	90467–12052	CLIP	2					
12	99530–08012	PIN, DOWEL	2					
13	95022–06070	BOLT, FLANGE	13					
14	93102–35805	OIL SEAL	1					
15	B74–E5453–00	GASKET	1					
16	91810–14809	PIN, DOWEL	2					
17	95022–06040	BOLT, FLANGE	10					
18	95022–06060	BOLT, FLANGE	1					
19	2PV–E5113–00	PLATE	1					
20	90340–12808	PLUG, STRAIGHT SCREW	1					
21	4YS–E1198–00	GASKET	1					
22	95812–08016	BOLT, FLANGE	1					
23	90430–08119	GASKET	1					
24	5LW–E5363–00	PLUG, OIL	1					
25	93210–14816	O-RING	1					
26	B74–E5421–00	COVER, CRANKCASE 2	1					
27	B74–E5461–00	GASKET, CRANKCASE COVER 2	1					




FIG. 10 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	91810–14809	PIN, DOWEL	2					
29	95022–08040	BOLT, FLANGE	6					




FIG. 11 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E5411–00	COVER, CRANKCASE 1	1					
2	B74–E5451–00	GASKET, CRANKCASE COVER 1	1					
3	91810–14809	PIN, DOWEL	1					
4	95022–06025	BOLT, FLANGE	12					
5	B74–E5431–00	COVER, CRANKCASE 3	1					
6	2DP–E5481–00	BOLT 1	4					
7	B74–E5471–00	DUCT, AIR	1					
8	95027–06016	BOLT, FLANGE	4					
9	B74–E5407–00	ELEMENT 1	1					
10	B74–E5474–00	SEAL, AIR DUCT	2					
11	90520–10837	DAMPER, PLATE	1					
12	90520–20821	DAMPER, PLATE	1					
13	90520–10835	DAMPER, PLATE	1					
14	B74–15338–00	DAMPER 5	1					




FIG. 12 STARTER

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E5512–00	GEAR, IDLER 1	1					
2	5BP–E5521–00	SHAFT 1	1					
3	B74–E5524–00	WHEEL, STARTER	1					
4	B74–E5590–00	STARTER ONE-WAY ASSY	1					
5	90110–06161	BOLT, HEXAGON SOCKET HEAD	6					





FIG. 13 CLUTCH


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–E7620–00	PRIMARY SLIDING SHEAVE COMP.	1					
2	B74–E7632–00	WEIGHT	6					
3	B74–E7623–00	CAM	1					
4	B74–E7653–00	SLIDER	3					
5	B74–E7674–00	COLLAR, GUIDE	1					
6	B74–E7611–00	SHEAVE, PRIMARY FIXED	1					
7	B74–E7660–00	SECONDARY FIXED SHEAVE COMP.	1					
8	B74–E7670–00	SECONDARY SLIDING SHEAVE	1					
9	B74–E7465–00	SEAL	2					
10	B74–E7465–10	SEAL	2					
11	B74–E7664–00	PIN, GUIDE	4					
12	B74–E7674–10	COLLAR, GUIDE	4					
13	B74–E7683–00	SPRING, SECONDARY	1					
14	B74–E7684–00	SEAT, SECONDARY SPRING	1					
15	B74–E7644–00	SEAT,SPRING	1					
16	B74–E7678–01	BEARING	1					
17	B74–E5744–00	CIRCLIP	1					
18	B74–E7678–10	BEARING	1					
19	B74–E6620–00	CLUTCH CARRIER ASSY	1					
20	B74–E7668–00	NUT	1					
21	B74–E6611–00	CLUTCH HOUSING COMP.	1					
22	90201–23015	WASHER, PLATE	1					
23	B74–E7641–00	V-BELT	1					
24	90201–19014	WASHER, PLATE	1					
25	90105–12807	BOLT, FLANGE	1					
26	90170–14802	NUT	1					
27	B74–E7412–00	BEARING	1					

FIG. 13 CLUTCH




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	99009–40700	CIRCLIP	1					

FIG. 14 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–17411–00	AXLE, MAIN (13T)	1					
2	B74–E6151–00	GEAR, PRIMARY DRIVEN (48T)	1					
3	93306–303YT	BEARING	2					
4	93306–272YC	BEARING	1					
5	B74–E7421–00	AXLE, DRIVE	1					
6	B74–E7211–00	GEAR, 1ST WHEEL (37T)	1					
7	99009–28400	CIRCLIP	1					
8	93306–304YW	BEARING	1					
9	93306–078Y1	BEARING	1					
10	99009–52500	CIRCLIP	1					
11	93102–35806	OIL SEAL	1					
12	B74–E6111–00	GEAR, PRIMARY DRIVE (18D)	1					
13	93300–205Y0	BEARING	1					
14	93102–25826	OIL SEAL	1					

FIG. 15 FRAME



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F1110–11	FRAME COMP.	1					
2	90520–04015	DAMPER, PLATE	2					
3	B74–H251P–00	BRACKET, MAIN SWITCH	1					
4	95022–06012	BOLT, FLANGE	2					
5	B74–F149S–00	BRACKET 5	1					
6	95022–06012	BOLT, FLANGE	1					
7	B74–F1400–01	ENGINE BRACKET COMP.	1					
8	B74–F2141–00	SHAFT, PIVOT	1					
9	90105–12806	BOLT, FLANGE	2					
10	90105–12805	BOLT, FLANGE	2					
11	95602–12200	NUT, SELF-LOCKING	5					




FIG. 16 FENDER

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F1511–00	FENDER, FRONT	1					
2	97702–50012	SCREW, TAPPING	4					
3	90179–06055	NUT	2					
4	B74–F1513–00–P4	STAY, FENDER 1	1					UR FOR MBL2
	B74–F1513–00–P5	STAY, FENDER 1	1					UR FOR MS1
5	90183–05807	NUT, SPRING	2					
6	B74–F1514–00–P4	STAY, FENDER 2	1					UR FOR MBL2
	B74–F1514–00–P5	STAY, FENDER 2	1					UR FOR MS1
7	90183–05807	NUT, SPRING	2					
8	90109–068A4	BOLT	4					
9	95027–06035	BOLT, FLANGE	2					
10	BG6–F1578–00	EMBLEM	2					UR FOR MBL2
	BG6–F1578–10	EMBLEM	2					UR FOR MS1
11	B74–F1651–00	COVER, REAR FENDER	1					
12	90183–05807	NUT, SPRING	1					
13	90269–06816	RIVET	4					
14	B74–F172A–00	PANEL 1	1					
15	97702–50012	SCREW, TAPPING	1					
16	90183–05807	NUT, SPRING	2					
17	90109–06887	BOLT	1					
18	B74–F172F–00	PANEL 2	1					
19	97702–50012	SCREW, TAPPING	1					
20	90183–05807	NUT, SPRING	2					
21	90109–06887	BOLT	1					
22	B74–F1611–00	FENDER, REAR	1					
23	90109–06887	BOLT	3					
24	2FC–H5111–00	REFLECTOR, FRONT 1	2					





FIG. 16 FENDER


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
25	95707–05500	NUT, FLANGE	2					
26	B74–H4550–00	LICENCE BRACKET ASSY	1					
27	90201–06088	WASHER, PLATE	2					
28	95602–06100	NUT, SELF-LOCKING	2					
29	4G0–21639–00	DAMPER 2	1					

FIG. 17 SIDE COVER




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F1731–00–P4	COVER, SIDE 3	1					UR FOR MBL2
	B74–F1731–00–P5	COVER, SIDE 3	1					UR FOR MS1
2	90183–05807	NUT, SPRING	2					
3	90480–01559	GROMMET	2					
4	B74–F474A–00–P4	ASSIST, GRIP	1					UR FOR MBL2
	B74–F474A–00–P5	ASSIST, GRIP	1					UR FOR MS1
5	97702–50016	SCREW, TAPPING	2					
6	97702–50012	SCREW, TAPPING	1					
7	90109–06887	BOLT	1					
8	95812–08020	BOLT, FLANGE	2					
9	90387–08839	COLLAR	2					
10	B74–F3469–00	CAP, BOLT	2					
11	B74–F173B–00	EMBLEM 3D	1					
12	B74–F1741–00–P4	COVER, SIDE 4	1					UR FOR MBL2
	B74–F1741–00–P5	COVER, SIDE 4	1					UR FOR MS1
13	90183–05807	NUT, SPRING	2					
14	90480–01559	GROMMET	2					
15	B74–F474W–00–P4	ASSIST,GRIP 2	1					UR FOR MBL2
	B74–F474W–00–P5	ASSIST,GRIP 2	1					UR FOR MS1
16	97702–50016	SCREW, TAPPING	2					
17	97702–50012	SCREW, TAPPING	1					
18	90109–06887	BOLT	1					
19	95812–08020	BOLT, FLANGE	2					
20	90387–08839	COLLAR	2					
21	B74–F3469–00	CAP, BOLT	2					
22	B74–F173B–00	EMBLEM 3D	1					
23	B74–F171E–00–P4	COVER, SIDE 5	1					UR FOR MBL2

FIG. 17 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
23	B74–F171E–00–P5	COVER, SIDE 5	1					UR FOR MS1
24	97702–50016	SCREW, TAPPING	2					
25	B74–F1871–00	TANK, RECOVERY	1					
26	1S7–F1875–01	CAP	1					
27	90109–06887	BOLT	1					
28	90480–13567	GROMMET	1					
29	B74–F1816–00	PIPE 1	1					
30	B74–F1817–00	PIPE 2	1					

FIG. 18 REAR ARM & SUPPENSION



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F2100–00	REAR ARM ASSY	1					
2	93306–303YV	.BEARING	1					
3	93106–28801	.OIL SEAL	1					
4	93106–28813	.OIL SEAL	1					
5	5MX–F2216–00	.BUSH, REAR SHOCK ABSORBER	1					
6	99009–47500	.CIRCLIP	1					
7	95812–10060	BOLT, FLANGE	2					
8	B74–F5183–00	COLLAR, WHEEL	1					
9	90387–17807	COLLAR	1					
10	90185–16800	NUT, SELF-LOCKING	1					
11	B74–F2210–00	SHOCK ABSORBER ASSY, REAR	2					
12	95817–10040	BOLT, FLANGE	2					
13	95602–10200	NUT, S/L FLANGE	2					
14	95817–08030	BOLT, FLANGE	2					





FIG. 19 STEERING


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	93399–999Y3	BEARING	1					
2	5BP–F3416–10	COVER, BALL RACE 2	1					
3	90179–25810	NUT	2					
4	90202–26142	WASHER, PLATE	1					
5	5BP–F3418–00	WASHER, SPECIAL	1					
6	B74–F3435–00	CROWN, HANDLE	1					
7	90179–22025	NUT	1					
8	91312–08030	BOLT, HEXAGON SOCKET HEAD	2					
9	B74–F312H–00	CLAMP	1					
10	95022–06012	BOLT, FLANGE	1					
11	B74–F3442–00	HOLDER, HANDLE LOWER	2					
12	B74–F3441–00	HOLDER, HANDLE UPPER	2					
13	95022–08055	BOLT, FLANGE	4					

FIG. 20 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F3102–00	FRONT FORK ASSY (L.H)	1					
2	B74–F3126–00	.TUBE, OUTER (L.H)	1					
3	B74–F3110–00	.INNER TUBE COMP.1	1					
4	B74–F3170–00	.CYLINDER COMP., FRONT FORK	1					
5	4HC–23125–20	.METAL, SLIDE 1	1					
6	22W–23146–L0	.WASHER, OIL SEAL	1					
7	5BP–F3145–00	.OIL SEAL	1					
8	22W–F3156–L0	.RING, SNAP	1					
9	5BP–F3144–00	.SEAL, DUST	1					
10	2CM–F3166–00	.SPACER, OIL LOCK	1					
11	2BU–F3158–00	.GASKET	1					
12	31B–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					
13	B74–F3141–00	.SPRING, FRONT FORK	1					
14	2JK–F3149–01	.WASHER, SPRING UPPER	1					
15	B74–F3118–00	.SPACER	1					
16	2JK–F3114–00	.GASKET	1					
17	5BP–F3111–10	.BOLT, CAP	1					
18	2N4–23168–00	.PLUG	1					
19	B74–F3103–00	FRONT FORK ASSY (R.H)	1					
20	B74–F3136–00	.TUBE, OUTER 2	1					
21	B74–F3110–00	.INNER TUBE COMP.1	1					
22	B74–F3170–00	.CYLINDER COMP., FRONT FORK	1					
23	4HC–23125–20	.METAL, SLIDE 1	1					
24	22W–23146–L0	.WASHER, OIL SEAL	1					
25	5BP–F3145–00	.OIL SEAL	1					
26	22W–F3156–L0	.RING, SNAP	1					
27	5BP–F3144–00	.SEAL, DUST	1					

FIG. 20 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	2CM–F3166–00	.SPACER, OIL LOCK	1					
29	2BU–F3158–00	.GASKET	1					
30	31B–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					
31	B74–F3141–00	.SPRING, FRONT FORK	1					
32	2JK–F3149–01	.WASHER, SPRING UPPER	1					
33	B74–F3118–00	.SPACER	1					
34	2JK–F3114–00	.GASKET	1					
35	5BP–F3111–10	.BOLT, CAP	1					
36	2N4–23168–00	.PLUG	1					
37	B74–F3340–00	UNDER BRACKET COMP.	1					
38	2JK–F3346–00	BOLT 1	2					
39	93399–99932	BEARING	1					
40	3FV–23462–00	SEAL, STEERING	1					
41	B65–F3123–00	COVER, UNDER 1	1					





FIG. 21 FUEL TANK


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F4110–01	FUEL TANK COMP.	1					
2	90464–13185	CLAMP	1					
3	5D9–F414G–00	SEAL	4					
4	90119–068A2	BOLT, WITH WASHER	4					
5	B74–E3907–00	FUEL PUMP COMP.	1					
6	3C1–F4519–00	.CLIP	1					
7	3C1–24512–00	.GASKET	1					
8	3C1–E3915–00	.FILTER	1					
9	B74–H5752–00	.SENDER UNIT ASSY, FUEL METER	1					
10	3C1–F4486–00	O-RING	1					
11	B74–F4425–00	BRACKET, FUEL PUMP 1	1					
12	91312–05010	BOLT, HEXAGON SOCKET HEAD	6					
13	B74–E3971–00	PIPE, FUEL 1	1					
14	B74–F419A–00	HOLDER	1					
15	95022–06012	BOLT, FLANGE	1					
16	B74–F4610–00	CAP ASSY	1					
17	B74–F414A–00	COVER, FILLER	1					
18	B74–F4313–00	PIPE 3	1					
19	1DW–F4180–02	ROLL OVER VALVE ASSY	1					
20	B74–F4135–00	CLAMP 1	1					
21	B74–F4314–00	PIPE 4	1					
22	B74–F4170–00	CANISTER ASSY	1					
23	B74–F483H–00	BAND	1					
24	B74–F452E–00	STAY	1					
25	B74–F454E–00	STAY 2	1					
26	95022–06012	BOLT, FLANGE	2					
27	90269–06816	RIVET	1					

FIG. 21 FUEL TANK




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	B74–F4315–00	PIPE 5	1					
29	90467–09006	CLIP	1					
30	90464–10008	CLAMP	1					
31	B74–F4316–00	PIPE 6	1					

FIG. 22 SEAT




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F4730–00	DOUBLE SEAT ASSY	1					
2	B74–F4741–00	.PAD, SEAT	4					
3	B74–F470F–00	.SEAT COVER COMP.	1					
4	B74–F4786–00	EMBLEM	1					
5	97702–40012	SCREW, TAPPING	2					
6	B74–F473R–00	BOX 1	1					
7	B74–F475M–00	SEAL	1					
8	B74–2476U–00	PROTECTOR 1	1					
9	B74–2476V–00	PROTECTOR,2	1					
10	B74–F4723–00	DAMPER, SEAT	1					
11	B74–H4770–00	LIGHT, ACCESSORY	1					
12	90520–10834	DAMPER, PLATE	3					
13	90338–06809	PLUG	2					
14	90109–06220	BOLT	5					
15	B74–F1621–00	FLAP	1					
16	90269–06816	RIVET	2					
17	B74–F4769–00	HINGE, SEAT	1					
18	95702–06500	NUT, FLANGE	4					
19	B74–F4785–00	MOLE, SEAT	1					
20	B74–F4727–00	PIN, SEAT FITTING	1					
21	90468–18121	CLIP	1					
22	B74–F4639–00	STOPPER, PLATE	1					
23	B74–F478G–00	STOPPER	1					
24	B74–F474E–00	ARM	1					
25	B74–F1121–00	BRACKET, DAMPER	1					
26	95022–08012	BOLT, FLANGE	2					
27	B74–F478E–00	CABLE, SEAT LOCK	1					

FIG. 22 SEAT



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	B65–F4780–00	SEAT LOCK ASSY	1					
29	95022–06012	BOLT, FLANGE	2					
30	B74–F472T–00	COVER, SEAT LOCK	1					
31	90269–06816	RIVET	4					
32	B74–F465E–00	ROTOR COMP.	1					
33	B74–F465B–00	CAP, ROTOR	1					
34	90464–36800	CLAMP	1					
35	92012–06020	BOLT, BUTTON HEAD	1					
36	B74–F471D–00	PLATE, LOCK 1	1					
37	91312–05010	BOLT, HEXAGON SOCKET HEAD	1					
38	B74–F479D–00	WIRE, SEAT LOCK 2	1					
39	1S7–F4768–00	STOPPER	1					
40	B74–F8100–00	TOOL KIT	1					
41	B74–F8175–00	HOLDER, TOOL	1					
42	1WD–F1668–01	LABEL, TIRE	1					

FIG. 23 FRONT WHEEL



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F5168–00–33	CAST WHEEL, FRONT	1					YB FOR MBL2,MS1
2	93106–22808	OIL SEAL	2					
3	933A6–202Y1	BEARING	2					
4	90387–15835	COLLAR	1					
5	94112–15800	TIRE (120/70-15 M/C 56P)	1					DUNLOP
6	93900–00828	VALVE, RIM	1					
7	5MT–25398–00	BALANCER, WHEEL (10G)	1					UN
	5MT–25398–10	BALANCER, WHEEL (20G)	1					UN
	5MT–25398–20	BALANCER, WHEEL (30G)	1					UN
8	2DP–F517G–00	ROTOR, SENSOR	1					
9	90149–05029	SCREW	3					
10	90387–15834	COLLAR	2					
11	B74–F5181–00	AXLE, WHEEL	1					
12	90201–15813	WASHER, PLATE	1					
13	90185–14801	NUT, SELF-LOCKING	1					





FIG. 24 FRONT BRAKE CALIPER

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F582U–00	DISK, BRAKE (RIGHT)	1					
2	90109–08232	BOLT	5					
3	B74–F580U–00	CALIPER ASSY (RIGHT)	1					
4	1WD–F5802–00	.PISTON ASSY, CALIPER	1					
5	1WD–F5803–00	..CALIPER SEAL KIT	1					
6	4C9–W0048–00	.BLEED SCREW KIT	1					
7	5YP–F5937–00	.BOOT 2	1					
8	5YP–F5917–00	.BOOT, CALIPER	1					
9	5YP–F5925–01	.CLIP	2					
10	1WD–F5919–00	.SUPPORT, PAD	1					
11	5YP–F5924–00	.PIN, PAD	1					
12	B74–F5805–00	.BRAKE PAD KIT	1					
13	90149–10804	SCREW	2					
14	B74–F3317–00	HOLDER, CABLE	1					

FIG. 25 REAR WHEEL






B741300-3250

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F5338–00–33	CAST WHEEL, REAR	1					YB FOR MBL2,MS1
2	94114–14803	TIRE (140/70-14 M/C 62P)	1					DUNLOP
3	93900–00828	VALVE, RIM	1					
4	5MT–25398–00	BALANCER, WHEEL (10G)	1					UN
	5MT–25398–10	BALANCER, WHEEL (20G)	1					UN
	5MT–25398–20	BALANCER, WHEEL (30G)	1					UN
5	2DP–F517G–00	ROTOR, SENSOR	1					
6	90149–05029	SCREW	3					

FIG. 26 REAR BRAKE CALIPER



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F582W–00	DISK, REAR BRAKE 2	1					
2	90111–08087	BOLT,HEX. SOCKET BUTTON	3					
3	B74–F580W–00	CALIPER ASSY, REAR 2	1					
4	1WD–F5802–50	.PISTON ASSY, CALIPER	1					
5	1WD–F5803–50	..CALIPER SEAL KIT	1					
6	5YP–F5917–00	.BOOT, CALIPER	1					
7	34X–25937–00	.BOOT 2	1					
8	5YP–W0048–50	.BLEED SCREW KIT	1					
9	B74–F5919–50	.SUPPORT, PAD	1					
10	1WD–F5924–50	.PIN, PAD	1					
11	5YP–F5925–01	.CLIP	2					
12	B74–F5921–50	.BRACKET, SUPPORT	1					
13	1WD–F5939–51	.CLIP, PAD	1					
14	1WD–F5939–61	.CLIP, PAD	1					
15	B74–F5806–00	.BRAKE PAD KIT 2	1					
16	1WD–F5914–50	.PIN, SLIDE	1					
17	5KN–25926–01	.BOLT	1					
18	5TL–F5838–00	.SLEEVE, CALIPER	1					
19	95812–10030	BOLT, FLANGE	2					




FIG. 27 STEERING HANDLE & CABLE

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F6110–00	HANDLE COMP.	1					
2	2DP–F6241–00	GRIP	1					
3	2DP–F6240–00	GRIP ASSY	1					
4	1PA–F6246–10	END, GRIP	2					
5	91317–06030	BOLT,HEX.SOCKET HEAD	2					
6	B74–F6301–00	THROTTLE CABLE ASSY	1					
7	92012–06010	BOLT, BUTTON HEAD	2					
8	92017–05016	BOLT, BUTTON HEAD	1					
9	B74–F637G–00	HOLDER, WIRE	1					
10	95022–06012	BOLT, FLANGE	1					
11	B74–F6280–00	REAR VIEW MIRROR ASSY (LEFT)	1					
12	B74–F6290–00	REAR VIEW MIRROR ASSY (RIGHT)	1					
13	B74–F6144–00	COVER, HANDLEBAR LOWER 1	1					
14	97702–50016	SCREW, TAPPING	4					
15	90183–06818	NUT, SPRING	1					
16	90183–05807	NUT, SPRING	1					
17	B74–F6213–00	COVER, UPPER	1					
18	90167–05076	SCREW, TAPPING	2					
19	90160–05808	SCREW, ROUND TAPPING	1					
20	90269–06816	RIVET	2					
21	B74–F6145–00–P0	COVER, HANDLE UPPER 2	1					MBL2 FOR MBL2,MS1
22	90149–06104	SCREW	1					
23	B74–F836B–00	TUNING FORK MARK	1					





FIG. 28 FRONT MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F5870–10	MASTER CYLINDER SUB ASSY	1					
2	B74–F5807–00	.CYLINDER KIT, MASTER	1					
3	5RB–25854–00	.DIAPHRAGM, RESERVOIR	1					
4	1WD–F5852–00	.CAP, RESERVOIR	1					
5	36Y–2589H–00	.SCREW	2					
6	B74–F5867–00	.BRACKET, MASTER CYLINDER	1					
7	3C1–F5855–00	.BUSH,DIAPHRAGM	1					
8	B74–H3922–00	LEVER 2	1					
9	95602–06100	NUT, SELF-LOCKING	1					
10	90109–06577	BOLT	1					
11	2DP–H3980–00	FRONT STOP SWITCH ASSY	1					
12	97602–04212	SCREW, PAN HEAD WITH WASHER	1					
13	95027–06025	BOLT, FLANGE	2					
14	B74–F5872–00	HOSE, BRAKE 1	1					
15	90401–10812	BOLT, UNION	2					
16	90201–10118	WASHER, PLATE	4					
17	B74–F5886–00	HOLDER, BRAKE HOSE	1					
18	95022–06012	BOLT, FLANGE	1					
19	B74–F5870–00	MASTER CYLINDER SUB ASSY	1					
20	B74–F5807–00	.CYLINDER KIT, MASTER	1					
21	5RB–25854–00	.DIAPHRAGM, RESERVOIR	1					
22	1WD–F5852–00	.CAP, RESERVOIR	1					
23	36Y–2589H–00	.SCREW	2					
24	B74–F5867–00	.BRACKET, MASTER CYLINDER	1					
25	3C1–F5855–00	.BUSH,DIAPHRAGM	1					
26	B74–H3912–00	LEVER 1	1					
27	95602–06100	NUT, SELF-LOCKING	1					

FIG. 28 FRONT MASTER CYLINDER



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	90109–06577	BOLT	1					
29	2DP–H2530–00	STOP SWITCH ASSY	1					
30	97602–04212	SCREW, PAN HEAD WITH WASHER	1					
31	95027–06025	BOLT, FLANGE	2					
32	B74–F5873–00	HOSE, BRAKE 2	1					
33	90401–10812	BOLT, UNION	2					
34	90201–10118	WASHER, PLATE	4					
35	B74–F5874–00	HOSE, BRAKE	1					
36	90401–10812	BOLT, UNION	2					
37	90201–10118	WASHER, PLATE	4					
38	B74–F5875–00	HOLDER, BRAKE HOSE 1	1					
39	95807–06012	BOLT, FLANGE	1					
40	B74–F5887–00	HOLDER, BRAKE HOSE	1					
41	95807–06012	BOLT, FLANGE	1					
42	B74–F581J–00	HOSE, BRAKE 4	1					
43	90401–10812	BOLT, UNION	2					
44	90201–10118	WASHER, PLATE	4					
45	90464–06008	CLAMP	1					
46	90464–07805	CLAMP	2					
47	B74–F5876–00	HOLDER, BRAKE HOSE 2	2					
48	95807–06010	BOLT, FLANGE	1					
49	95802–06012	BOLT, FLANGE	1					
50	B74–F587A–00	HOLDER, BRAKE HOSE	1					
51	95802–06012	BOLT, FLANGE	1					





FIG. 29 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F8385–00	COVER, UNDER	1					
2	90183–05807	NUT, SPRING	1					
3	90109–06887	BOLT	1					
4	B74–F838N–00	DUCT 1	1					
5	97702–50016	SCREW, TAPPING	3					
6	B74–F7111–00	STAND, MAIN	1					
7	90506–40805	SPRING, TENSION	1					
8	45P–F7114–00	STOPPER, MAIN STAND	1					
9	B74–F7261–00	SHAFT	1					
10	93430–12809	CIRCLIP	1					
11	B74–F7311–00	STAND, SIDE	1					
12	90506–32813	SPRING, TENSION	1					
13	90101–10830	BOLT	1					
14	95602–10200	NUT, S/L FLANGE	1					
15	90387–10849	COLLAR	1					
16	4YY–F7114–00	STOPPER, MAIN STAND	1					
17	B74–F7430–00	REAR FOOTREST ASSY 1	1					
18	2DP–F7431–01	.FOOTREST, REAR 1	1					
19	B74–F741L–00	.BRACKET 4	1					
20	90501–12743	.SPRING, COMPRESSION	1					
21	93501–04830	.BALL	1					
22	91702–08038	.PIN, CLEVIS	1					
23	91402–25015	.PIN, COTTER	1					
24	B74–F7437–00	.WASHER, SPECIAL	1					
25	95812–08016	BOLT, FLANGE	2					
26	B74–F7440–00	REAR FOOTREST ASSY 2	1					
27	2DP–F7441–01	.FOOTREST, REAR 2	1					

FIG. 29 STAND & FOOTREST



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	B74–F742L–00	.BRACKET 5	1					
29	90501–12743	.SPRING, COMPRESSION	1					
30	93501–04830	.BALL	1					
31	91702–08038	.PIN, CLEVIS	1					
32	91402–25015	.PIN, COTTER	1					
33	B74–F7437–00	.WASHER, SPECIAL	1					
34	95812–08016	BOLT, FLANGE	2					




FIG. 30 STAND & FOOTREST 2

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F7481–00	BOARD, FOOTREST	1					
2	90480–01559	GROMMET	2					
3	90464–04004	CLAMP	2					
4	97702–50012	SCREW, TAPPING	2					
5	B74–F171L–00–P4	MOLE, SIDE COVER 1	1					UR FOR MBL2
	B74–F171L–00–P5	MOLE, SIDE COVER 1	1					UR FOR MS1
6	90183–05807	NUT, SPRING	2					
7	90269–09005	RIVET	1					
8	90109–06887	BOLT	2					
9	90119–06051	BOLT, WITH WASHER	2					
10	97702–50012	SCREW, TAPPING	1					
11	2DP–F172W–00	COVER	1					
12	B74–F7488–00	BOARD, FOOTREST 2	1					
13	90480–01559	GROMMET	2					
14	90464–04004	CLAMP	2					
15	97702–50012	SCREW, TAPPING	2					
16	B74–F171M–00–P4	MOLE, SIDE COVER 2	1					UR FOR MBL2
	B74–F171M–00–P5	MOLE, SIDE COVER 2	1					UR FOR MS1
17	90183–05807	NUT, SPRING	2					
18	90269–09005	RIVET	1					
19	90109–06887	BOLT	2					
20	90119–06051	BOLT, WITH WASHER	2					
21	97702–50012	SCREW, TAPPING	1					
22	90160–05808	SCREW, ROUND TAPPING	1					
23	B74–F1711–00–P2	COVER, SIDE 1	1					UR SMX FOR MBL2
	B74–F1711–00–P0	COVER, SIDE 1	1					UR MBL2 FOR MS1
24	90160–05808	SCREW, ROUND TAPPING	2					





FIG. 30 STAND & FOOTREST 2


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
25	90111–06839	BOLT,HEX. SOCKET BUTTON	1					
26	90183–05807	NUT, SPRING	1					
27	B74–F1721–00–P2	COVER, SIDE 2	1					UR SMX FOR MBL2
	B74–F1721–00–P0	COVER, SIDE 2	1					UR MBL2 FOR MS1
28	90160–05808	SCREW, ROUND TAPPING	2					
29	90111–06839	BOLT,HEX. SOCKET BUTTON	1					
30	90183–05807	NUT, SPRING	1					
31	B74–F7483–00	MAT 1	1					
32	B74–F7484–00	MAT 2	1					
33	B74–F7493–00	MAT 3	1					
34	B74–F7494–00	MAT 4	1					

FIG. 31 LEG SHIELD



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F836K–00	PANEL, INNER 1	1					
2	90160–05808	SCREW, ROUND TAPPING	2					
3	97702–50012	SCREW, TAPPING	2					
4	B74–F8346–00–P0	MOLE 2	1					MBL2 FOR MBL2,MS1
5	B74–F8311–00	LEG SHIELD 1	1					
6	90183–05807	NUT, SPRING	12					
7	B74–F836L–00	PANEL, INNER 2	1					
8	90183–05807	NUT, SPRING	2					
9	B74–F839L–00	LID 2	1					
10	90520–06808	DAMPER, PLATE	1					
11	97707–50012	SCREW, TRUSS HEAD TAPPING	2					
12	B74–F818A–00	PIN	2					
13	90508–13800	SPRING, TORSION	1					
14	B74–F834F–00	DAMPER	1					
15	B74–F838L–00	BOX 2	1					
16	90183–06818	NUT, SPRING	2					
17	B74–F8349–00	CAP	1					
18	4US–F6199–00	PLUG, BLIND	1					
19	97707–50012	SCREW, TRUSS HEAD TAPPING	3					
20	B74–F8357–00	STAY 2	1					
21	95022–06012	BOLT, FLANGE	2					
22	1DY–F4780–00	SEAT LOCK ASSY	1					
23	95022–06012	BOLT, FLANGE	2					
24	B74–F836M–00	PANEL, INNER 3	1					
25	90183–05807	NUT, SPRING	2					
26	B74–F839V–00	LID 3	1					
27	90520–06808	DAMPER, PLATE	1					

FIG. 31 LEG SHIELD



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	B74–F8336–00	PLATE	1					
29	97707–50012	SCREW, TRUSS HEAD TAPPING	2					
30	B74–F818A–00	PIN	2					
31	90508–13801	SPRING, TORSION	1					
32	B74–F834F–00	DAMPER	1					
33	B74–F838V–00	BOX 3	1					
34	4US–F6199–00	PLUG, BLIND	1					
35	90464–13801	CLAMP	1					
36	97707–50012	SCREW, TRUSS HEAD TAPPING	3					
37	90109–06887	BOLT	2					
38	B74–F835X–00	WIRE	1					
39	B74–F8365–00	COVER	1					
40	90269–06812	RIVET	2					
41	90119–06051	BOLT, WITH WASHER	2					
42	90269–06816	RIVET	4					
43	97702–50016	SCREW, TAPPING	4					
44	B74–F74A8–00–P0	LID, FUEL	1					MBL2 FOR MBL2,MS1
45	90183–05807	NUT, SPRING	1					
46	B74–F839W–00	LID 4	1					
47	4G0–21639–00	DAMPER 2	2					
48	97702–50012	SCREW, TAPPING	1					
49	B74–F818A–00	PIN	2					
50	90508–14803	SPRING, TORSION	1					
51	B74–F834F–00	DAMPER	1					
52	B74–F838W–00	BOX 4	1					
53	90183–06818	NUT, SPRING	2					
54	1DY–F4780–00	SEAT LOCK ASSY	1					





FIG. 31 LEG SHIELD


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
55	95022–06012	BOLT, FLANGE	2					
56	B74–F4494–00	WIRE, PULL	1					
57	97527–05512	BOLT, WITH WASHER	1					
58	90109–06220	BOLT	2					
59	B74–F8312–00–P0	LEG SHIELD 2	1					MBL2 FOR MBL2,MS1
60	90269–06816	RIVET	6					
61	B74–F842M–00	COVER 1	1					
62	97702–50012	SCREW, TAPPING	2					
63	B74–F837L–00	PANEL, CONSOLE 1	1					
64	90269–06816	RIVET	2					
65	B74–F837M–00	PANEL, CONSOLE 2	1					
66	90269–06816	RIVET	2					

FIG. 32 WINDSHIELD



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–F837N–00	GRILL, AIR INTAKE 1	1					
2	90119–06051	BOLT, WITH WASHER	3					
3	90160–05808	SCREW, ROUND TAPPING	2					
4	90269–06816	RIVET	4					
5	90183–05807	NUT, SPRING	2					
6	B74–F8321–00	STAY 1	1					
7	90480–10289	GROMMET	1					
8	90480–14229	GROMMET	3					
9	90387–068N8	COLLAR	3					
10	95802–06020	BOLT, FLANGE	3					
11	95812–08055	BOLT, FLANGE	2					
12	B74–H212B–00	BOX, BATTERY 1	1					
13	90109–06887	BOLT	1					
14	90387–09805	COLLAR	2					
15	90179–06841	NUT	2					
16	90183–05807	NUT, SPRING	2					
17	90183–06818	NUT, SPRING	5					
18	90387–06048	COLLAR	2					
19	90387–09808	COLLAR	8					
20	90111–06839	BOLT,HEX. SOCKET BUTTON	4					
21	95022–06012	BOLT, FLANGE	2					
22	B74–F8306–00	PLATE, WINDSHIELD	1					
23	B74–F835P–00	PLATE, WINDSHIELD 2	1					
24	B74–F8322–00	STAY 2	1					
25	B74–F8332–00	STAY, LEG SHIELD	1					
26	90110–06380	BOLT, HEXAGON SOCKET HEAD	2					
27	90109–06009	BOLT	2					

FIG. 32 WINDSHIELD



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	90179–05003	NUT	4					
29	B74–F286F–00	COVER, FRONT 2	1					
30	90183–05807	NUT, SPRING	2					
31	97702–50016	SCREW, TAPPING	2					
32	97702–50012	SCREW, TAPPING	5					
33	90480–01558	GROMMET	2					
34	B74–F8351–00–P4	BODY, COWLING	1					UR FOR MBL2
	B74–F8351–00–P5	BODY, COWLING	1					UR FOR MS1
35	95802–06025	BOLT, FLANGE	1					
36	90480–14023	GROMMET	1					
37	90387–06158	COLLAR	1					
38	97702–50012	SCREW, TAPPING	2					
39	B74–F835J–00–P1	BODY, FRONT UNDER 1	1					UR SMX FOR MBL2
	B74–F835J–00–P0	BODY, FRONT UNDER 1	1					UR MBL2 FOR MS1
40	97702–50016	SCREW, TAPPING	3					
41	90183–05807	NUT, SPRING	5					
42	B74–F414B–00	EMBLEM	1					
43	B74–F8377–00–P4	BODY, COWLING 2	1					UR FOR MBL2
	B74–F8377–00–P5	BODY, COWLING 2	1					UR FOR MS1
44	95802–06025	BOLT, FLANGE	1					
45	90480–14023	GROMMET	1					
46	90387–06158	COLLAR	1					
47	97702–50012	SCREW, TAPPING	2					
48	B74–F835K–00–P0	BODY, FRONT UNDER 2	1					UR MBL2 FOR MS1
	B74–F835K–00–P1	BODY, FRONT UNDER 2	1					UR SMX FOR MBL2
49	97702–50016	SCREW, TAPPING	3					
50	90183–05807	NUT, SPRING	5					





FIG. 32 WINDSHIELD


REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
51	B74–F414B–00	EMBLEM	1					
52	B74–F2865–00–P0	COVER, FRONT	1					MBL2 FOR MBL2,MS1
53	90464–07018	CLAMP	2					
54	90183–05807	NUT, SPRING	2					
55	B74–H2129–00	COVER, BATTERY	1					
56	97702–50012	SCREW, TAPPING	2					
57	90183–05807	NUT, SPRING	2					
58	90269–06816	RIVET	1					
59	B74–F837U–00	SCREEN	1					
60	90150–05024	SCREW, ROUND HEAD	4					
61	B74–F842A–00	COVER 5	1					
62	B74–F843C–00	COVER 6	1					
63	90269–08007	RIVET	2					
64	2PH–F1737–00	EMBLEM	1					

FIG. 33 GENERATOR




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H1450–00	ROTOR ASSY	1					
2	B74–H1410–00	STATOR ASSY	1					
3	90110–06178	BOLT, HEXAGON SOCKET HEAD	3					
4	90110–06161	BOLT, HEXAGON SOCKET HEAD	2					

FIG. 34 STARTING MOTOR




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H1890–00	MOTOR ASSY	1					
2	B74–H1801–00	.BRUSH SET	1					
3	1WD–H1861–00	.GASKET	2					
4	1WD–H1828–00	.BOLT 2	2					
5	4FP–H182L–00	.O-RING 1	1					
6	B74–H1948–00	BRACKET	1					
7	90110–06172	BOLT, HEXAGON SOCKET HEAD	2					

FIG. 35 FLASHER LIGHT




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H3310–00	FRONT FLASHER LIGHT ASSY 1	1					
2	2CB–H3311–00	.BULB, FLASHER (12V-10W)	1					
3	B74–H3312–00	.LENS, FLASHER	1					
4	B74–H4723–00	.GASKET, TAIL LENS	1					
5	B74–H4140–00	.SOCKET CORD ASSY	1					
6	97702–50012	SCREW, TAPPING	2					
7	90464–04004	CLAMP	1					
8	B74–H3320–00	FRONT FLASHER LIGHT ASSY 2	1					
9	2CB–H3311–00	.BULB, FLASHER (12V-10W)	1					
10	B74–H3322–00	.LENS, FLASHER 2	1					
11	B74–H4723–00	.GASKET, TAIL LENS	1					
12	B74–H4150–00	.SOCKET CORD ASSY 2	1					
13	97702–50012	SCREW, TAPPING	2					
14	90464–04004	CLAMP	1					

FIG. 36 METER




REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H3500–00	METER ASSY	1					
2	B74–H353L–00	.REFLECTOR	1					
3	B74–H3511–00	.LENS, SPEEDOMETER	1					
4	B74–H3572–00	.CASE, SPEEDOMETER LOWER	1					
5	97702–30016	.SCREW, TAPPING	7					
6	97702–50016	SCREW, TAPPING	4					

FIG. 37 HEADLIGHT



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H4300–00	HEADLIGHT ASSY	1					
2	95802–06020	BOLT, FLANGE	2					
3	90480–10289	GROMMET	2					
4	90387–06899	COLLAR	2					
5	90183–05807	NUT, SPRING	4					

FIG. 38 TAILLIGHT



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H4710–00	TAILLIGHT UNIT ASSY	1					
2	97702–40612	.SCREW, TAPPING	1					
3	1YT–83311–00	.BULB(12V-10W)	1					
4	90183–05807	NUT, SPRING	2					
5	90109–06887	BOLT	1					
6	97702–50012	SCREW, TAPPING	1					
7	B74–H4730–00	TAILLIGHT UNIT ASSY	1					
8	97702–40612	.SCREW, TAPPING	1					
9	1YT–83311–00	.BULB(12V-10W)	1					
10	90183–05807	NUT, SPRING	2					
11	90109–06887	BOLT	1					
12	97702–50016	SCREW, TAPPING	1					
13	97702–50012	SCREW, TAPPING	1					
14	90464–16006	CLAMP	1					
15	3C1–H5130–00	REAR REFLECTOR ASSY	1					
16	95702–05500	NUT, FLANGE	1					
17	B74–H4740–00	LICENCE LIGHT ASSY	1					
18	1WD–H4744–00	.BULB (12V-5W)	1					
19	B74–H4547–00	.CORD, LICENCE LIGHT	1					
20	B74–H454J–00	.CLAMP, CORD	2					
21	1WD–H4726–00	.SCREW	2					
22	92017–05012	BOLT, BUTTON HEAD	2					
23	B74–H4748–00	NUT, SPECIAL	1					




FIG. 39 HANDLE SWITCH & LEVER

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H3963–00	SWITCH, HANDLE 3	1					
2	98507–05040	.SCREW, PAN HEAD	2					
3	B74–H3973–10	SWITCH, HANDLE 3	1					
4	98507–05025	.SCREW, PAN HEAD	2					




FIG. 40 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H591A–00	ENGINE CONTROL UNIT ASSY	1					
2	B74–H2591–00	BAND	1					
3	1WD–H2100–00	BATTERY ASSY (GS GTZ8V)	1					
4	B74–H2131–00	BAND, BATTERY	1					
5	2GS–H1960–01	RECTIFIER & REGULATOR ASSY	1					
6	95822–06025	BOLT, FLANGE	2					
7	B74–H1815–00	CORD, STARTER MOTOR	1					
8	98902–05008	SCREW, BIND	1					
9	B74–H1940–00	STARTER RELAY ASSY	1					
10	B74–H2151–A0	.FUSE (20A)	1					
11	1WD–H2155–00	.BAND	1					
12	91312–05008	BOLT, HEXAGON SOCKET HEAD	2					
13	B74–H2590–01	WIRE HARNESS ASSY	1					
14	B65–H2151–00	.FUSE (7.5A)	7					
15	B65–H2151–10	.FUSE (15A)	2					
16	B65–H2151–60	.FUSE (30A)	2					
17	B65–H2151–80	.FUSE (2A)	3					
18	1LB–H2151–00	.FUSE (10A)	2					
19	1SD–H5700–00	.THERMISTOR ASSY	1					
20	4WA–81980–00	.DIODE ASSY	1					
21	3WP–81980–00	.DIODE ASSY	2					
22	95022–06012	BOLT, FLANGE	2					
23	90464–36800	CLAMP	1					
24	90464–24230	CLAMP	1					
25	90464–10008	CLAMP	1					
26	90464–12018	CLAMP	1					
27	90464–10112	CLAMP	1					(160X8.00)




FIG. 40 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
28	90464–36006	CLAMP	1					
29	B74–H2566–00	SWITCH, SIDE STAND	1					
30	90111–05810	BOLT,HEX. SOCKET BUTTON	2					
31	B74–H2501–00	MAIN SWITCH STEERING LOCK	1					
32	B74–H276E–00	KNOB COMP.	1					
33	90464–09806	CLAMP	2					
34	90109–06319	BOLT	2					
35	B74–H6260–40	REMOTE CONTROL UNIT ASSY	1					
36	B74–H6261–40	.XMTR. COMP.	1					
37	B65–H5546–00	BAND	1					
38	90464–30001	CLAMP	1					
39	B74–H1950–00	RELAY ASSY	3					
40	1PA–H2576–00	SENSOR, LEAN ANGLE	1					
41	BB8–H254B–00	TERMINAL COMP.	1					
42	B3F–H3383–00	BUZZER	1					
43	97702–50016	SCREW, TAPPING	1					





FIG. 41 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H2310–00	IGNITION COIL ASSY	1					
2	95022–06016	BOLT, FLANGE	2					
3	B74–H2370–00	PLUG CAP ASSY	1					
4	B74–H592A–10	SENSOR, OXYGEN	1					
5	90464–12018	CLAMP	1					
6	54P–H3591–00	THERMO UNIT	1					
7	90430–10804	GASKET	1					
8	4GY–83350–00	FLASHER RELAY ASSY	1					
9	1WD–H3371–00	HORN	1					
10	95022–08012	BOLT, FLANGE	1					

FIG. 42 ELECTRICAL 3



REF. NO.	PART NO.	DESCRIPTION	B74C					REMARKS
1	B74–H5930–09	HYDRAULIC UNIT ASSY	1					
2	B74–H5970–00	WHEEL SENSOR ASSY, FRONT	1					
3	95802–06016	BOLT, FLANGE	1					
4	90464–14803	CLAMP	2					
5	B74–H5112–00	BRACKET, REFLECTOR 1	1					
6	91312–06016	BOLT, HEXAGON SOCKET HEAD	2					
7	B74–H5980–00	WHEEL SENSOR ASSY, REAR	1					
8	95802–06016	BOLT, FLANGE	1					

PART NO.	REF. NO.
B74–11391–00	1 – 18
B74–11416–00	2 – 9
B74–11416–10	2 – 9
B74–11416–20	2 – 9
B74–11416–30	2 – 9
B74–11416–40	2 – 9
B74–11416–50	2 – 9
B74–11416–A0	2 – 9
B74–11417–00	2 – 10
B74–11417–10	2 – 10
B74–11417–20	2 – 10
B74–11417–30	2 – 10
B74–11417–40	2 – 10
B74–11417–50	2 – 10
B74–11417–A0	2 – 10
B74–11650–00	2 – 2
2C0–11654–00	2 – 3
B74–11656–00	2 – 5
B74–11656–10	2 – 5
B74–11656–20	2 – 5
B74–11656–30	2 – 5
B74–12168–00	3 – 13
B74–12168–20	3 – 13
B74–12168–40	3 – 13
B74–12168–60	3 – 13
B74–12168–80	3 – 13
B74–12168–A0	3 – 13
B74–12168–F0	3 – 13
B74–12168–H0	3 – 13
B74–12168–K0	3 – 13
B74–12168–M0	3 – 13
B74–12168–R0	3 – 13
B74–12168–U0	3 – 13
B74–12168–W0	3 – 13
B74–12168–Y0	3 – 13
B74–12169–10	3 – 13
B74–12169–30	3 – 13
B74–12169–50	3 – 13
B74–12169–70	3 – 13
B74–12169–90	3 – 13
B74–12169–E0	3 – 13
B74–12169–G0	3 – 13
B74–12169–J0	3 – 13
B74–12169–L0	3 – 13
B74–12169–N0	3 – 13
B74–12169–T0	3 – 13
B74–12169–V0	3 – 13
B74–12169–X0	3 – 13
B74–1216A–00	3 – 13
B74–1216A–20	3 – 13
B74–1216A–40	3 – 13
B74–1216A–60	3 – 13
B74–1216A–80	3 – 13
B74–1216A–A0	3 – 13
B74–1216A–F0	3 – 13
B74–1216A–H0	3 – 13
B74–1216A–K0	3 – 13
B74–1216A–M0	3 – 13
B74–1216A–R0	3 – 13
B74–1216A–U0	3 – 13
B74–1216A–W0	3 – 13
B74–1216A–Y0	3 – 13
31G–12210–01	4 – 16
31G–12214–00	4 – 18
31G–12222–00	4 – 17
B74–12410–00	6 – 1
52S–12439–00	6 – 2
5GJ–12675–00	6 – 12
5RU–13490–00	7 – 5
52S–13938–00	8 – 9
B74–15338–00	11 – 14
5PW–15361–00	5 – 16
B74–17411–00	14 – 1
4G0–21639–00	16 – 29
	31 – 47
4HC–23125–20	20 – 5
	20 – 23
22W–23146–L0	20 – 6
	20 – 24
2N4–23168–00	20 – 18
	20 – 36
3FV–23462–00	20 – 40
3C1–24512–00	21 – 7
B74–2476U–00	22 – 8
B74–2476V–00	22 – 9
5MT–25398–00	23 – 7
	25 – 4
5MT–25398–10	23 – 7
	25 – 4
5MT–25398–20	23 – 7
	25 – 4
5RB–25854–00	28 – 3
	28 – 21
36Y–2589H–00	28 – 5
	28 – 23
5KN–25926–01	26 – 17
34X–25937–00	26 – 7
3WP–81980–00	40 – 21
4WA–81980–00	40 – 20
1YT–83311–00	38 – 3
	38 – 9
4GY–83350–00	41 – 8
B74–E1102–00	1 – 1
B74–E111F–00	4 – 8
40D–E1126–00	10 – 9
B74–E112F–00	4 – 6
B74–E1133–10	1 – 2
B74–E1166–00	8 – 39
B74–E1169–00	1 – 11
B74–E1181–00	1 – 20
B74–E1185–00	1 – 10
B74–E1191–00	1 – 9
B74–E1193–00	1 – 13
4YS–E1198–00	10 – 21
B74–E1311–00	1 – 24
B74–E1351–00	1 – 25
B74–E1400–00	2 – 1
B74–E1500–00	2 – 11
B74–E1603–00	2 – 15
B74–E1631–01	2 – 14
B74–E1633–00	2 – 16
B74–E1998–00	1 – 7
B74–E1999–00	1 – 14
B74–E2111–00	3 – 1
B74–E2113–00	3 – 4
B74–E2117–00	3 – 6
5TL–E2118–00	3 – 5
54P–E2119–00	3 – 3
B74–E2121–00	3 – 2
2PH–E2126–00	3 – 7
B74–E2146–00	3 – 10
B74–E2151–00	3 – 8
B74–E2157–00	5 – 4
B74–E2161–00	3 – 9
B74–E2170–00	4 – 1
B74–E2176–00	4 – 4
B74–E2213–00	4 – 19
1DB–E2228–00	4 – 15
B74–E2231–00	4 – 11
B74–E2233–00	4 – 12
B74–E2241–00	4 – 14
B74–E2405–00	6 – 10
B74–E240A–00	6 – 7
B74–E2422–00	5 – 1
B74–E2439–00	5 – 2
B74–E2446–00	6 – 39
B74–E2450–00	5 – 12
B74–E2461–00	6 – 13
B65–E2462–00	6 – 32
B74–E2467–00	6 – 36
B74–E2481–00	6 – 21
B74–E2482–00	6 – 26
B74–E2483–00	6 – 27
B74–E2484–00	6 – 33
B74–E2576–00	6 – 4
B74–E2591–00	6 – 30
5ST–E2615–00	6 – 8
B74–E2662–00	3 – 11
1WD–E2671–00	6 – 11
5ST–E2843–00	6 – 9
B74–E3300–00	7 – 1
4ST–E3411–00	7 – 4
1S7–E3440–00	7 – 7
B74–E3447–00	7 – 8
B74–E3585–00	8 – 1
B74–E3595–00	8 – 2
B74–E3750–01	8 – 13
B74–E3761–00	8 – 6
B74–E3770–00	8 – 5
B74–E3907–00	21 – 5
3C1–E3915–00	21 – 8
B74–E3971–00	21 – 13
54P–E4137–00	8 – 10
54P–E4147–00	8 – 7
5CA–E4147–00	8 – 8
54P–E416A–00	8 – 17
54P–E4243–00	8 – 15
B74–E4335–00	8 – 18
B74–E4411–00	8 – 19
B74–E4412–00	8 – 20
B74–E4417–00	8 – 33
B74–E4435–00	8 – 30
B74–E4437–00	8 – 22
52B–E443E–00	8 – 27
5TP–E443G–10	8 – 31
B74–E4449–00	8 – 29
B74–E4452–00	8 – 24
B74–E4462–00	8 – 34
B74–E4469–00	8 – 21
B74–E447F–00	8 – 43
B74–E4611–00	9 – 1
1WD–E4613–00	9 – 13
B74–E4711–00	9 – 2
54D–E4714–00	9 – 3
1WD–E4715–00	9 – 4
B74–E4718–00	9 – 6
B74–E475P–00	9 – 10
B74–E476P–00	9 – 11
B74–E477P–00	9 – 12
B74–E4799–00	9 – 9
2PV–E5113–00	10 – 19
B74–E5150–00	10 – 1
5D9–E5155–00	10 – 2
5LW–E5363–00	10 – 24
5BP–E5363–10	5 – 6
B74–E5372–00	10 – 3
B74–E5373–00	10 – 10
B74–E5378–00	10 – 4
B74–E5407–00	11 – 9
B74–E5411–00	11 – 1
B74–E5417–00	5 – 3
B74–E5421–00	10 – 26
B74–E5431–00	11 – 5
B74–E5451–00	11 – 2
B74–E5453–00	10 – 15
B74–E5461–00	10 – 27
B74–E5471–00	11 – 7
B74–E5474–00	11 – 10
2DP–E5481–00	11 – 6
B74–E5512–00	12 – 1
5BP–E5521–00	12 – 2
B74–E5524–00	12 – 3
B74–E5590–00	12 – 4
B74–E5744–00	13 – 17
B74–E6111–00	14 – 12
B74–E6151–00	14 – 2
B74–E6611–00	13 – 21
B74–E6620–00	13 – 19
B74–E7211–00	14 – 6
B74–E7412–00	13 – 27
B74–E7421–00	14 – 5
B74–E7465–00	13 – 9
B74–E7465–10	13 – 10
B74–E7611–00	13 – 6
B74–E7620–00	13 – 1
B74–E7623–00	13 – 3
B74–E7632–00	13 – 2
B74–E7641–00	13 – 23
B74–E7644–00	13 – 15
B74–E7653–00	13 – 4
B74–E7660–00	13 – 7
B74–E7664–00	13 – 11
B74–E7668–00	13 – 20
B74–E7670–00	13 – 8
B74–E7674–00	13 – 5
B74–E7674–10	13 – 12
B74–E7678–01	13 – 16
B74–E7678–10	13 – 18
B74–E7683–00	13 – 13
B74–E7684–00	13 – 14
B74–F1110–11	15 – 1
B74–F1121–00	22 – 25
B74–F1400–01	15 – 7
B74–F149S–00	15 – 5
B74–F1511–00	16 – 1
B74–F1513–00–P4	16 – 4
B74–F1513–00–P5	16 – 4
B74–F1514–00–P4	16 – 6
B74–F1514–00–P5	16 – 6
BG6–F1578–00	16 – 10
BG6–F1578–10	16 – 10
B74–F1611–00	16 – 22
B74–F1621–00	22 – 15
B74–F1651–00	16 – 11
1WD–F1668–01	22 – 42
B74–F1711–00–P0	30 – 23
B74–F1711–00–P2	30 – 23
B74–F171E–00–P4	17 – 23
B74–F171E–00–P5	17 – 23
B74–F171L–00–P4	30 – 5
B74–F171L–00–P5	30 – 5
B74–F171M–00–P4	30 – 16
B74–F171M–00–P5	30 – 16
B74–F1721–00–P0	30 – 27
B74–F1721–00–P2	30 – 27
B74–F172A–00	16 – 14
B74–F172F–00	16 – 18
2DP–F172W–00	30 – 11
B74–F1731–00–P4	17 – 1
B74–F1731–00–P5	17 – 1
2PH–F1737–00	32 – 64
B74–F173B–00	17 – 11
	17 – 22
B74–F1741–00–P4	17 – 12
B74–F1741–00–P5	17 – 12
B74–F1816–00	17 – 29
B74–F1817–00	17 – 30
B74–F1823–00	6 – 22

PART NO.	REF. NO.
B74–F1871–00	17 – 25
1S7–F1875–01	17 – 26
B74–F2100–00	18 – 1
B74–F2141–00	15 – 8
B74–F2210–00	18 – 11
5MX–F2216–00	10 – 8
	18 – 5
B74–F2591–00	6 – 24
B74–F2865–00–P0	32 – 52
B74–F286F–00	32 – 29
B74–F3102–00	20 – 1
B74–F3103–00	20 – 19
B74–F3110–00	20 – 3
	20 – 21
5BP–F3111–10	20 – 17
	20 – 35
2JK–F3114–00	20 – 16
	20 – 34
B74–F3118–00	20 – 15
	20 – 33
B65–F3123–00	20 – 41
B74–F3126–00	20 – 2
B74–F312H–00	19 – 9
B74–F3136–00	20 – 20
B74–F3141–00	20 – 13
	20 – 31
5BP–F3144–00	20 – 9
	20 – 27
5BP–F3145–00	20 – 7
	20 – 25
2JK–F3149–01	20 – 14
	20 – 32
22W–F3156–L0	20 – 8
	20 – 26
2BU–F3158–00	20 – 11
	20 – 29
2CM–F3166–00	20 – 10
	20 – 28
B74–F3170–00	20 – 4
	20 – 22
31B–F3181–00	20 – 12
	20 – 30
B74–F3317–00	24 – 14
B74–F3340–00	20 – 37
2JK–F3346–00	20 – 38
5BP–F3416–10	19 – 2
5BP–F3418–00	19 – 5
B74–F3435–00	19 – 6

PART NO.	REF. NO.
B74–F3441–00	19 – 12
B74–F3442–00	19 – 11
B74–F3469–00	17 – 10
	17 – 21
B74–F4110–01	21 – 1
B74–F4135–00	21 – 20
B74–F414A–00	21 – 17
B74–F414B–00	32 – 42
	32 – 51
5D9–F414G–00	21 – 3
B74–F4170–00	21 – 22
1DW–F4180–02	21 – 19
B74–F419A–00	21 – 14
B74–F4313–00	21 – 18
B74–F4314–00	21 – 21
B74–F4315–00	21 – 28
B74–F4316–00	21 – 31
B74–F4425–00	21 – 11
3C1–F4486–00	21 – 10
B74–F4494–00	31 – 56
3C1–F4519–00	21 – 6
B74–F452E–00	21 – 24
B74–F454E–00	21 – 25
B74–F4610–00	21 – 16
B74–F4639–00	22 – 22
B74–F465B–00	22 – 33
B74–F465E–00	22 – 32
B74–F470F–00	22 – 3
B74–F471D–00	22 – 36
B74–F4723–00	22 – 10
B74–F4727–00	22 – 20
B74–F472T–00	22 – 30
B74–F4730–00	22 – 1
B74–F473R–00	22 – 6
B74–F4741–00	22 – 2
B74–F474A–00–P4	17 – 4
B74–F474A–00–P5	17 – 4
B74–F474E–00	22 – 24
B74–F474W–00–P4	17 – 15
B74–F474W–00–P5	17 – 15
B74–F475M–00	22 – 7
1S7–F4768–00	22 – 39
B74–F4769–00	22 – 17
1DY–F4780–00	31 – 22
	31 – 54
B65–F4780–00	22 – 28
B74–F4785–00	22 – 19
B74–F4786–00	22 – 4

PART NO.	REF. NO.
B74–F478E–00	22 – 27
B74–F478G–00	22 – 23
B74–F479D–00	22 – 38
B74–F483H–00	21 – 23
B74–F5168–00–33	23 – 1
2DP–F517G–00	23 – 8
	25 – 5
B74–F5181–00	23 – 11
B74–F5183–00	18 – 8
B74–F5338–00–33	25 – 1
1WD–F5802–00	24 – 4
1WD–F5802–50	26 – 4
1WD–F5803–00	24 – 5
1WD–F5803–50	26 – 5
B74–F5805–00	24 – 12
B74–F5806–00	26 – 15
B74–F5807–00	28 – 2
	28 – 20
B74–F580U–00	24 – 3
B74–F580W–00	26 – 3
B74–F581J–00	28 – 42
B74–F582U–00	24 – 1
B74–F582W–00	26 – 1
5TL–F5838–00	26 – 18
1WD–F5852–00	28 – 4
	28 – 22
3C1–F5855–00	28 – 7
	28 – 25
B74–F5867–00	28 – 6
	28 – 24
B74–F5870–00	28 – 19
B74–F5870–10	28 – 1
B74–F5872–00	28 – 14
B74–F5873–00	28 – 32
B74–F5874–00	28 – 35
B74–F5875–00	28 – 38
B74–F5876–00	28 – 47
B74–F587A–00	28 – 50
B74–F5886–00	28 – 17
B74–F5887–00	28 – 40
1WD–F5914–50	26 – 16
5YP–F5917–00	24 – 8
	26 – 6
1WD–F5919–00	24 – 10
B74–F5919–50	26 – 9
B74–F5921–50	26 – 12
5YP–F5924–00	24 – 11
1WD–F5924–50	26 – 10

PART NO.	REF. NO.
5YP–F5925–01	24 – 9
	26 – 11
5YP–F5937–00	24 – 7
1WD–F5939–51	26 – 13
1WD–F5939–61	26 – 14
B74–F6110–00	27 – 1
B74–F6144–00	27 – 13
B74–F6145–00–P0	27 – 21
4US–F6199–00	31 – 18
	31 – 34
B74–F6213–00	27 – 17
2DP–F6240–00	27 – 3
2DP–F6241–00	27 – 2
1PA–F6246–10	27 – 4
B74–F6280–00	27 – 11
B74–F6290–00	27 – 12
B74–F6301–00	27 – 6
B74–F637G–00	27 – 9
B74–F7111–00	29 – 6
45P–F7114–00	29 – 8
4YY–F7114–00	29 – 16
B74–F7261–00	29 – 9
B74–F7311–00	29 – 11
B74–F741L–00	29 – 19
B74–F742L–00	29 – 28
B74–F7430–00	29 – 17
2DP–F7431–01	29 – 18
B74–F7437–00	29 – 24
	29 – 33
B74–F7440–00	29 – 26
2DP–F7441–01	29 – 27
B74–F7481–00	30 – 1
B74–F7483–00	30 – 31
B74–F7484–00	30 – 32
B74–F7488–00	30 – 12
B74–F7493–00	30 – 33
B74–F7494–00	30 – 34
B74–F74A8–00–P0	31 – 44
B74–F8100–00	22 – 40
B74–F8175–00	22 – 41
B74–F818A–00	31 – 12
	31 – 30
	31 – 49
B74–F8306–00	32 – 22
B74–F8311–00	31 – 5
B74–F8312–00–P0	31 – 59
B74–F8321–00	32 – 6
B74–F8322–00	32 – 24

PART NO.	REF. NO.
B74–F8332–00	32 – 25
B74–F8336–00	31 – 28
B74–F8346–00–P0	31 – 4
B74–F8349–00	31 – 17
B74–F834F–00	31 – 14
	31 – 32
	31 – 51
B74–F8351–00–P4	32 – 34
B74–F8351–00–P5	32 – 34
B74–F8357–00	31 – 20
B74–F835J–00–P0	32 – 39
B74–F835J–00–P1	32 – 39
B74–F835K–00–P0	32 – 48
B74–F835K–00–P1	32 – 48
B74–F835P–00	32 – 23
B74–F835X–00	31 – 38
B74–F8365–00	31 – 39
B74–F836B–00	27 – 23
B74–F836K–00	31 – 1
B74–F836L–00	31 – 7
B74–F836M–00	31 – 24
B74–F8377–00–P4	32 – 43
B74–F8377–00–P5	32 – 43
B74–F837L–00	31 – 63
B74–F837M–00	31 – 65
B74–F837N–00	32 – 1
B74–F837U–00	32 – 59
B74–F8385–00	29 – 1
B74–F838L–00	31 – 15
B74–F838N–00	29 – 4
B74–F838V–00	31 – 33
B74–F838W–00	31 – 52
B74–F839L–00	31 – 9
B74–F839V–00	31 – 26
B74–F839W–00	31 – 46
B74–F842A–00	32 – 61
B74–F842M–00	31 – 61
B74–F843C–00	32 – 62
B74–H1410–00	33 – 2
B74–H1450–00	33 – 1
B74–H1801–00	34 – 2
B74–H1815–00	40 – 7
1WD–H1828–00	34 – 4
4FP–H182L–00	34 – 5
1WD–H1861–00	34 – 3
B74–H1890–00	34 – 1
B74–H1940–00	40 – 9
B74–H1948–00	34 – 6

PART NO.	REF. NO.
B74–H1950–00	40 – 39
2GS–H1960–01	40 – 5
1WD–H2100–00	40 – 3
B74–H2129–00	32 – 55
B74–H212B–00	32 – 12
B74–H2131–00	40 – 4
1LB–H2151–00	40 – 18
B65–H2151–00	40 – 14
B65–H2151–10	40 – 15
B65–H2151–60	40 – 16
B65–H2151–80	40 – 17
B74–H2151–A0	40 – 10
1WD–H2155–00	40 – 11
B74–H2310–00	41 – 1
B74–H2370–00	41 – 3
B74–H2501–00	40 – 31
B74–H251P–00	15 – 3
2DP–H2530–00	28 – 29
BB8–H254B–00	40 – 41
B74–H2566–00	40 – 29
1PA–H2576–00	40 – 40
B74–H2590–01	40 – 13
B74–H2591–00	40 – 2
B74–H276E–00	40 – 32
B74–H3310–00	35 – 1
2CB–H3311–00	35 – 2
	35 – 9
B74–H3312–00	35 – 3
B74–H3320–00	35 – 8
B74–H3322–00	35 – 10
1WD–H3371–00	41 – 9
B3F–H3383–00	40 – 42
B74–H3500–00	36 – 1
B74–H3511–00	36 – 3
B74–H353L–00	36 – 2
B74–H3572–00	36 – 4
54P–H3591–00	41 – 6
B74–H3912–00	28 – 26
B74–H3922–00	28 – 8
B74–H3963–00	39 – 1
B74–H3973–10	39 – 3
2DP–H3980–00	28 – 11
B74–H4140–00	35 – 5
B74–H4150–00	35 – 12
B74–H4300–00	37 – 1
B74–H4547–00	38 – 19
B74–H454J–00	38 – 20
B74–H4550–00	16 – 26

PART NO.	REF. NO.
B74–H4710–00	38 – 1
B74–H4723–00	35 – 4
	35 – 11
1WD–H4726–00	38 – 21
B74–H4730–00	38 – 7
B74–H4740–00	38 – 17
1WD–H4744–00	38 – 18
B74–H4748–00	38 – 23
B74–H4770–00	22 – 11
2FC–H5111–00	16 – 24
B74–H5112–00	42 – 5
3C1–H5130–00	38 – 15
B65–H5546–00	40 – 37
1SD–H5700–00	40 – 19
B74–H5752–00	21 – 9
B74–H5801–00	8 – 16
B74–H591A–00	40 – 1
B74–H592A–10	41 – 4
B74–H5930–09	42 – 1
B74–H5970–00	42 – 2
B74–H5980–00	42 – 7
B74–H6260–40	40 – 35
B74–H6261–40	40 – 36
4C9–W0048–00	24 – 6
5YP–W0048–50	26 – 8
B74–WE445–00	8 – 23
90101–10830	29 – 13
90105–10883	2 – 6
90105–12805	15 – 10
90105–12806	15 – 9
90105–12807	13 – 25
90109–06009	32 – 27
90109–06220	22 – 14
	31 – 58
90109–06319	40 – 34
90109–06577	28 – 10
	28 – 28
90109–06887	6 – 37
	16 – 17
	16 – 21
	16 – 23
	17 – 7
	17 – 18
	17 – 27
	29 – 3
	30 – 8
	30 – 19
	31 – 37
90109–06887	32 – 13
	38 – 5
	38 – 11
90109–068A4	16 – 8
90109–08232	24 – 2
90110–06161	12 – 5
	33 – 4
90110–06172	8 – 4
	34 – 7
90110–06178	33 – 3
90110–06182	4 – 13
90110–06187	4 – 7
90110–06380	32 – 26
90110–06405	4 – 5
90110–06868	1 – 23
90111–05810	40 – 30
90111–06807	9 – 7
90111–06839	30 – 25
	30 – 29
	32 – 20
90111–08087	26 – 2
90119–06051	30 – 9
	30 – 20
	31 – 41
	32 – 2
90119–068A2	21 – 4
90149–05029	23 – 9
	25 – 6
90149–06104	27 – 22
90149–10804	24 – 13
90150–05024	32 – 60
90160–05808	27 – 19
	30 – 22
	30 – 24
	30 – 28
	31 – 2
	32 – 3
90167–05076	27 – 18
90170–14802	13 – 26
90179–05003	32 – 28
90179–06055	16 – 3
90179–06841	32 – 15
90179–07001	2 – 4
90179–10818	1 – 16
90179–22025	19 – 7
90179–25810	19 – 3
90183–05807	16 – 5
	16 – 7
90183–05807	16 – 12
	16 – 16
	16 – 20
	17 – 2
	17 – 13
	27 – 16
	29 – 2
	30 – 6
	30 – 17
	30 – 26
	30 – 30
	31 – 6
	31 – 8
	31 – 25
	31 – 45
	32 – 5
	32 – 16
	32 – 30
	32 – 41
	32 – 50
	32 – 54
	32 – 57
	37 – 5
	38 – 4
	38 – 10
90183–06818	27 – 15
	31 – 16
	31 – 53
	32 – 17
90185–14801	23 – 13
90185–16800	18 – 10
90201–06033	6 – 16
90201–06088	16 – 27
90201–10118	28 – 16
	28 – 34
	28 – 37
	28 – 44
90201–10848	2 – 7
90201–10849	1 – 17
90201–15813	23 – 12
90201–18262	10 – 5
90201–19014	13 – 24
90201–23015	13 – 22
90202–26142	19 – 4
90269–06812	31 – 40
90269–06816	6 – 38
	16 – 13
	21 – 27
90269–06816	22 – 16
	22 – 31
	27 – 20
	31 – 42
	31 – 60
	31 – 64
	31 – 66
	32 – 4
	32 – 58
90269–07007	6 – 31
90269–08007	32 – 63
90269–09005	30 – 7
	30 – 18
90280–05013	2 – 8
90338–06809	22 – 13
90338–14802	8 – 36
90340–12808	10 – 20
90340–18002	1 – 3
90340–32805	5 – 10
90387–06048	32 – 18
90387–06158	32 – 37
	32 – 46
90387–064W3	6 – 15
90387–06899	37 – 4
90387–068N8	32 – 9
90387–08839	17 – 9
	17 – 20
90387–09805	32 – 14
90387–09808	32 – 19
90387–10849	29 – 15
90387–15834	23 – 10
90387–15835	23 – 4
90387–17807	18 – 9
90401–10812	28 – 15
	28 – 33
	28 – 36
	28 – 43
90430–06014	1 – 5
	5 – 9
90430–08119	10 – 23
90430–10148	5 – 5
90430–10804	41 – 7
90450–52008	8 – 38
90450–56009	8 – 12
90464–04004	30 – 3
	30 – 14
	35 – 7
	35 – 14
90464–06008	28 – 45
90464–07018	32 – 53
90464–07805	28 – 46
90464–09806	40 – 33
90464–10008	21 – 30
	40 – 25
90464–10112	40 – 27
90464–10802	6 – 6
90464–12018	40 – 26
	41 – 5
90464–13185	21 – 2
90464–13801	31 – 35
90464–14803	42 – 4
90464–16006	38 – 14
90464–24230	40 – 24
90464–30001	40 – 38
90464–36006	40 – 28
90464–36800	22 – 34
	40 – 23
90467–09006	21 – 29
90467–10038	6 – 5
90467–12052	10 – 11
90467–12809	8 – 28
	8 – 32
90467–13808	8 – 40
90467–14807	8 – 41
90467–20805	6 – 28
90467–21801	6 – 29
90467–22002	6 – 19
90467–24800	6 – 20
90467–250A1	6 – 34
90467–26131	6 – 35
90468–18121	22 – 21
90480–01558	32 – 33
90480–01559	17 – 3
	17 – 14
	30 – 2
	30 – 13
90480–10289	32 – 7
	37 – 3
90480–10332	9 – 8
90480–13567	17 – 28
90480–14023	32 – 36
	32 – 45
90480–14229	32 – 8
90480–14818	6 – 18
90480–15483	6 – 14
90501–12743	29 – 20
90501–12743	29 – 29
90506–32813	29 – 12
90506–40805	29 – 7
90508–13800	31 – 13
90508–13801	31 – 31
90508–14803	31 – 50
90520–04015	15 – 2
90520–06808	31 – 10
	31 – 27
90520–10834	22 – 12
90520–10835	11 – 13
90520–10836	8 – 42
90520–10837	11 – 11
90520–20821	11 – 12
91312–05008	40 – 12
91312–05010	21 – 12
	22 – 37
91312–05014	3 – 12
91312–06016	42 – 6
91312–06025	4 – 20
91312–08030	19 – 8
91317–06030	27 – 5
91402–25015	29 – 23
	29 – 32
91702–08038	29 – 22
	29 – 31
91810–14809	10 – 16
	10 – 28
	11 – 3
92012–06010	27 – 7
92012–06020	22 – 35
92017–05012	38 – 22
92017–05016	27 – 8
93102–25826	14 – 14
93102–35805	10 – 14
93102–35806	14 – 11
93103–10801	5 – 14
93106–22808	23 – 2
93106–28801	18 – 3
93106–28813	18 – 4
93210–10096	7 – 6
93210–12801	4 – 2
93210–14816	10 – 25
93210–18397	10 – 7
93210–198J0	5 – 7
93210–22800	6 – 40
93210–32816	5 – 11
93210–40659	8 – 3

PART NO.	REF. NO.
93210–48530	7 – 10
93300–205Y0	14 – 13
93306–000Y3	5 – 13
93306–002XH	4 – 3
93306–078Y1	14 – 9
93306–204XV	2 – 13
93306–272YC	14 – 4
93306–303YT	2 – 12
	14 – 3
93306–303YV	18 – 2
93306–304YW	14 – 8
93399–99932	20 – 39
93399–999Y3	19 – 1
933A6–202Y1	23 – 3
93430–12809	29 – 10
93450–17129	2 – 17
93501–04830	29 – 21
	29 – 30
93900–00828	23 – 6
	25 – 3
94112–15800	23 – 5
94114–14803	25 – 2
94568–F9058	7 – 3
94568–H8110	4 – 10
94700–00436	1 – 19
95022–06012	1 – 4
	1 – 8
	4 – 9
	6 – 23
	6 – 25
	15 – 4
	15 – 6
	19 – 10
	21 – 15
	21 – 26
	22 – 29
	27 – 10
	28 – 18
	31 – 21
	31 – 23
	31 – 55
	32 – 21
	40 – 22
95022–06016	1 – 12
	41 – 2
95022–06020	6 – 3
	7 – 9
95022–06025	1 – 15

PART NO.	REF. NO.
95022–06025	11 – 4
95022–06040	10 – 17
95022–06060	7 – 2
	10 – 18
95022–06070	10 – 13
95022–08012	22 – 26
	41 – 10
95022–08040	10 – 29
95022–08055	19 – 13
95027–06016	11 – 8
95027–06020	5 – 8
95027–06025	28 – 13
	28 – 31
95027–06035	16 – 9
95027–08035	9 – 5
95602–06100	16 – 28
	28 – 9
	28 – 27
95602–10200	18 – 13
	29 – 14
95602–12200	15 – 11
95612–08620	1 – 6
95702–05500	38 – 16
95702–06500	22 – 18
95702–08500	9 – 14
95707–05500	16 – 25
95802–06012	28 – 49
	28 – 51
95802–06016	42 – 3
	42 – 8
95802–06020	32 – 10
	37 – 2
95802–06025	32 – 35
	32 – 44
95807–06010	28 – 48
95807–06012	28 – 39
	28 – 41
95812–06025	8 – 11
95812–06030	8 – 37
95812–08016	10 – 22
	29 – 25
	29 – 34
95812–08020	17 – 8
	17 – 19
95812–08055	32 – 11
95812–10030	26 – 19
95812–10060	18 – 7
95817–08030	18 – 14

PART NO.	REF. NO.
95817–10040	18 – 12
95817–10045	9 – 15
95822–06025	40 – 6
95827–06020	6 – 41
95827–06025	6 – 17
97527–05512	31 – 57
97602–04212	28 – 12
	28 – 30
97702–30016	36 – 5
97702–40012	22 – 5
97702–40612	38 – 2
	38 – 8
97702–50012	16 – 2
	16 – 15
	16 – 19
	17 – 6
	17 – 17
	30 – 4
	30 – 10
	30 – 15
	30 – 21
	31 – 3
	31 – 48
	31 – 62
	32 – 32
	32 – 38
	32 – 47
	32 – 56
	35 – 6
	35 – 13
	38 – 6
	38 – 13
97702–50016	17 – 5
	17 – 16
	17 – 24
	27 – 14
	29 – 5
	31 – 43
	32 – 31
	32 – 40
	32 – 49
	36 – 6
	38 – 12
	40 – 43
97702–50020	8 – 35
97707–50012	31 – 11
	31 – 19
	31 – 29

PART NO.	REF. NO.
97707–50012	31 – 36
97707–50025	8 – 25
97707–50035	8 – 26
98502–06012	8 – 14
98507–05025	39 – 4
98507–05040	39 – 2
98902–05008	40 – 8
99009–10400	5 – 15
99009–18400	10 – 6
99009–28400	14 – 7
99009–40700	13 – 28
99009–47500	18 – 6
99009–52500	14 – 10
99530–08012	10 – 12
99530–14016	1 – 21
	1 – 22